




MEASURING SOLAR HEATING & POOL COVERS

State the "Actual Roof Measurements" on your order.

When measuring a roof, it's very important to include the actual measurements, rather than the solar collector measurements. That way, we can make the solar system to suit the roof shape.


- When measuring all roofs, you must take down the below measurements.
- With systems that have more than one section, these measurements must be taken for each section, i.e Section A and B.
- Only roof measurements will be accepted on our forms, so please make sure you do not make any allowance in your measuring for the header pipes. We will do that for you.
- Indicate in the diagram section where the solar is to be located, i.e "keep high on roof".
- Indicate skylight or flue locations.



METAL ROOF MEASUREMENTS:

- A: Top of Roof Length**
- B: Bottom of Roof Length**
- C: Manifold Side Length (Angled or Straight)**
- D: Top to Bottom of Roof**

* Remember to take measurements internal of capping, flashing & ridges.



TILED ROOF MEASUREMENTS:

The measurements described above are required for a tiled roof along with the following 2 additions:


- (1.) The exposed tile length from top to bottom.
- (2.) Number of tiles from top to bottom.

* Orders cannot be processed without a tile length.

How to measure for a Pool Cover

No matter what the shape of the pool, measure as if a rectangle, i.e Widest & Longest points.

Always take the waterline measurement under the coping tile.



Ordering Tips:

Measure the roof/pool, ensuring you get all the required measurements listed above.

Fill in as many details as possible on a Sunbather Order Form (pages 19-25) or your letterhead paper.

Please ensure customer name, purchase order number and colour is provided with every job for tracking purposes.

Fax or email your orders to your nearest Sunbather Office.

Note: Sunbather only accepts purchase orders via fax or email.